

# Hardware Transmit Lockout for the TS-590S and the TS-590SG

Steve London, N2IC

Locate Q904 on the **foil side** of the TX-RX board. The TX-RX board is accessed by removing the bottom cover of the TS-590. The board must be removed to access the foil side. In the attached drawings, Q904 is shown, circled in the top, left corner.

Connect 2 wires to Q904. One wire to the base, the other to the emitter.

To inhibit transmit, short the two wires together using a relay or other means. Do **not** short either wire to ground.

Thanks to E7DX and S55M for this information.



